

iBert safe-T-seat Pad Assembly Instructions

1. Unbuckle the shoulder straps from the crotch strap buckle.
2. Slide the crotch strap through the slot in the bottom of the pad.
3. Insert the 3 push pins through the 3 holes in the seat pad and fasten them into the 3 holes in the backrest of the safe-T-seat.
4. Enjoy the ride!!